


# **BLASTER**

*Instructions Manual*

MAXX  
RX  
UNIQUE  
REVOLUTION

“ Thank you for purchasing a Kyklon® product. It has been built to your satisfaction. Likewise any electrical equipment, there are some precautions to be taken before, during and after using a Kyklon® dryer. ”



CLIP  
CUSTOMER RELATIONSHIP



CAUTIONS AND PRECAUTIONS



QUICK ASSEMBLY



INSTRUCTIONS FOR USE



SAFETY AND MAINTENANCE



PROBLEMS SOLUTION



WARRANTY




### Care instructions

- Likewise any other electrical equipment, there are some precautions to be taken before, during and after using a Kyklon® Force Dryer:
- Use a 15 amperes capacity outlet.
- Do not leave the equipment unattended while it is on. To avoid accidents unplug the equipment whenever it is not in use or the operator leaves the room.
- If the equipment gets wet or falls into water do not try to reach it. Unplug it immediately. In this case do not try to repair it yourself, take it to an authorized service.
- Do not insert objects in the equipment's holes nor allow any particles to enter the equipment.
- In the event that the cord or the plug are damaged, or the equipment makes unusual noise, take it to the nearest authorized service.
- Deformation or melting of plug is caused by a defective contact with the outlet, which needs to be replaced.
- Do not use the equipment if the power network is defective.
- An improper or faulty outlet might cause power loss, burning of the plug, and damage to the equipment.
- Do not make adaptations or use devices different from the ones supplied by the manufacturer.
- Drops and hits are fatal to the motor.
- Do not block or choke the air outlet.
- When the hairdryer is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the hairdryer is switched off (IEC 60335-2-23).
- For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your electrician for advice (IEC 60335-2-23).
- This machine is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the machine by a person responsible for their safety. Children should be supervised to ensure that they do not play with the machine (IEC 60335-1).
- If the supply cord is damaged, it must be replaced by the manufacturer or service agent or similarly qualified person in order to avoid risks (IEC 60335-1).

### Assembly instructions:

- Nozzle: Models Super, RX and Revolution screw the nozzle on the hose turning counter-clockwise.
- Adapter: Models Super, RX and Revolution install the adapter in the hose turning counter-clockwise.
- Models Maxx, Unique, RX and Revolution attach the adapter into the blower nozzle up to the end of its course and screw it.
- Model Super, attach the adapter in the nozzle up to the end of its course.



To assemble the shoulder strap: Insert the ring "1" into the bracket hole "2" of the blaster (Fig 01).  
Important: Before connecting the equipment to the power outlet, make sure that available voltage is same as required by the equipment and that the switch is set to the "off" position ("0" position).

## Usage Instructions

The Force Dryer is an efficient tool for removing excess water from the hair of the pets. The use of the Kyklon® Force Dryers is also recommended when using easy bathing to wash animals or when disinfecting areas or accommodations.

To remove excess water from the hair, turn on the Force Dryer and direct the air jet to the body of the animal in the opposite direction to that of the hair. To speed up the process even more, use a towel to dry the water being expelled.

Start from the back of the animal downwards in the direction of the legs.

Do not direct air jet to sensitive parts such as eyes, ears, nostrils, mouth, genitals, anus, wounds, stitches and other parts which may cause discomfort to the animal.

## MAINTENANCE

### Carbon Brushes

Do not attempt to repair the equipment. If the equipment needs servicing, send it to an authorized service.

Force Dryers, including Kyklon, operate with a carbon brush-type motor which life span is of about 500 working hours.

For this reason, send your equipment to an authorized service when this period is reached or around expiring (3 to 4 months of use).

Brushes are items which wear off. The more the equipment is used the more the brushes wear off.

Replacing the brushes in due time will enhance the life span of the motor. Since this is a task which requires specific skill take the Force Dryer to an authorized technician to have the brushes replaced.

The carbon brushes life span is influenced by the level of humidity in the working environment, level of dust or use of equipment when the filter is dirty or defective.

### Heating

Force Dryers do not have an heating element. Air heating is a consequence of the cooling of the motor where the air circulates. The air temperature will be about 50% higher than the room temperature after 2 to 4 minutes of work. Higher room temperature means higher heating.

### Air filter

The air filter must be kept clean. Dirt reduces air flow and causes motor overheating.

To clean the filter unplug the equipment from the power network. Replace filter if blocked or damaged.

Under no circumstance operate the blower without a filter or with a damaged filter to avoid accidents and protect the motor.

Never turn on the equipment without its rear cover/filter in place.

Replace filter every three months at least.

### Warranty

This equipment has a warranty against manufacturing and workmanship defects for a period of three months. (Valid in Brazil).

More details about the warranty can be found in the Warranty Certificate.

The warranty does not cover

- Carbon brushes as they are wearing parts.
- The motor, when it is proved that the defect was caused by normal wear off or by excess of dirt.
- Hoses and other parts damaged by animal bites or improper handling.
- Damage resulting from accidents, improper use or use which does not follow to specifications.

**WARNING: the breaking of the seal by an unauthorized person cancels the warranty.**



**WARNING!** Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

Product manufactured by  
Clippertec Industrial e Comercial Ltda  
E-mail: [clippertec@clippertec.com.br](mailto:clippertec@clippertec.com.br) Site: [www.clippertec.com.br](http://www.clippertec.com.br)

Distributor:  
Kainix Limited  
138 Gloucester Road, Ocean Down - Mount Maungamui  
Bay of Plenty, 3116 - New Zealand

**CLIPPertec®**